



Orion Incorporation Limited

Flat A, 8 Floor, Block A, Marvel Industrial Building, 25-31 Kwai Fung Crescent,
Kwai Chung, N.T., HK.

Tel : (852)2615 9533 Fax : (852)2480 4234 www.orionzero.hk

3 stations Pen plating Machine



Set up:

- 1) Switch on at the back
- 2) Adjust voltage with the front knot. (1V-12V)
- 3) All three Plating Pens operate at the same time.

Red: Plating Pen Anode

Black: Cathode

4) Instead of clipping directly, can tie copper or silver wire around the pieces for application.



- 5) Make sure one felt tip for one kind of plating material

- 6) Polish and clean pieces the same as electroplating bath